$\Gamma$ 





FIG. 1



 $\Gamma$ 




FIG. 3

$\Gamma$	B	$B_{\ell}$	DI B.	В	
BATTERY FULL	BATTERY TOP OFF	LOW / NORMAL BATTERY	DEPLETED BATTERY	NO BATTERY	
FIG. 4	B 20 16 21 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		A 20 16 21 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		NO CHARGER PRESENT
$\left \begin{array}{cccccccccccccccccccccccccccccccccccc$	G 20 16 21 - TOP OFF - J J FINAL TOP OFF	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	D 20 16 21	$\begin{array}{c} C \\ \downarrow \\ \downarrow \\ \downarrow \\ \downarrow \\ \end{array}$	LOW POWER CHARGER PRESENT CAN SUPPLY APPLICATION IN LOW CURRENT MODES  HIGH POWER CHARGER PRESENT CAN SUPPLY APPLICATION IN ALL MODES